# **JetPompa Operating Manual**













#### EC DECLARATION OF CONFORMITY

#### AT UYGUNLUK BEYANI

Manufacturer / İmalatcı : MAS DAF MAKINA SANAYI A.S.

Address / Adres : Orta Mahallesi, Atavolu Caddesi No: 16 Tuzla 34956 İSTANBUL / TÜRKİYE

Name and address of the person authorised to Vahdettin YIRTMAC

compile the technical file

Orta Mahallesi, Atayolu Caddesi No: 16 Tuzla 34956 İSTANBUL /

Teknik Dosyayı Derleyen Yetkili Kişi ve Adresi

The undersigned Company certifies under its sole responsibility that the item of equipment specified below satisfies the requirements of the mainly Machinery Directive 2006/42/EC which is apply to it.

The item of equipment identified below has been subject to internal manufacturing checks with monitoring of the final assessment by MAS DAF MAKINA SANAYI A.S.

. Aşağıda tanımlanmış olan ürünler için Makine Emniyeti yönetmeliği 2006 / 42 / AT' nin uygulanabilen gerekliliklerinin yerine getirildiğini ve sorumluluğun alınmış olunduğunu beyan ederiz.

Aşağıda tanımlanan ürünler iç üretim kontrollerine bağlı olarak MAS DAF MAKİNA SANAYİ A.Ş. tarafından kontrol edilmistir

Equipment / Ürün : Self-Priming Stainless Steel Jet pumps / Kendinden Emişli Paslanmaz Çelik Jet Pompalar

Seri / Model-Tip : Jet Series - Jet Serisi

For pumps supplied with drivers/ Elektrikli Pompa Üniteleri

Related Directives / Yönetmelikler

2006/42/EC Machinery Directive / 2006/42/AT Makine Emniyeti Yönetmeliği 2014/35/EU Low Voltage Directive / 2014/35/AB Alçak Gerilim Yönetmeliği

2014/30/EU Electromagnetic Compatibility Directive / 2014/30/AB Elektromanyetik Uyumluluk Yönetmeliği

EUP 2009/ 125 /EC Electric Used Products Directive/ Elektrik Kullanan Ekipmanlar Direktifi (EUP)

Regulations applied acc. to harmonize standards / Uygulanan Uyumlaştırılmış Standartlar TS EN ISO 12100:2010, TS EN 809+A1, TS EN 60204-1:2018.

We hereby declare that this equipment is intended to be incorporated into, or assembled with other machinery to constitute relevant machinery to comply with essential health and safety requirements of Directive The machinery covered by this declaration must not be put into service until the relevant machinery into which it is tobe incorporated has been declared in conformity with provisions of the directive.

Ekipman, uygun bir makina oluşturmak amacıyla diğer ekipmanlar ile birleştirilirken ya da monte edilirken gerekli sağlık ve güvenlik yönetmeliklerine uyulması gerekmektedir.

Bu bildiri kapsamında yönetmelikte belirtilen bütün hükümler yerine getirilmeden makinanın devreye alınmaması gerekmektedir.

Place and date of issue / Yer ve Tarih Name and position of authorized person Vetkili Kişinin Adı ve Görevi Signature of authorized person Yetkili Kişinin İmzası

: İstanbul, 01.08.2019 : Vahdettin YIRTMAC General Manader / Genel Müdür



TABLE OF CONTENTS	Page N	lo
Introduction		3
1- Important Safety Precautions		3
2- General		4
2.1. Application Fields of Pump		4
2.2. Performance Information		4
2.3. Warranty Conditions 2.4. Test		4
3- Safe Operating Conditions		4
3.1. Training of Personnel		4
3.2. Hazardous Conditions That May Occur	r When	7
One does not Comply with the Safety Instruct		5
3.3. Safety Measures for Operator		5
3.4. Safety Measures for Maintenance and	l	
Installation		5
3.5. Spare Parts Replacement		5
4- Technical Information		5
4.1. Design		555556
5- Transport and Storage 5.1. Transport		5
5.2. Storage		6
6- Installation		6
6.1. Installation		6
6.2. Electrical Connection		6
7- Commissioning, Start Up and Operating		6
7.1. Check the Rotary Direction		7
7.2. Check Before Pump Start-Up		7
7.3. Frequency of Pump Starts		7
7.4. Frost Protecting 7.5. The Following Should be Checked Reg	ulaely	/
for Pump	utarty	7
8- Maintenance		7777
8.1. The Checks During the Operation		7
8.2. Service		7
8.3. Spare Parts		8
9- Possible Failures, Causes, Solutions		9
10-Sectional Drawing and Part List for Jet Pur		10
11- Drawing for Dismantling and Part List for Je	t Pump	1
<b>□</b> Λ		

# INTRODUCTION /!\



· This manual contains instructions for the installation, operation and maintenance of the Jet series are self-priming light horizontal shaft centrifugal pumps of MAS DAF MAKINA SANAYI A.S.

· Please read carefully this manual and apply all the instructions to operate pumps without problems. Pumps shall be used for their intended duties. In this manual, there are information on operating conditions, installation, starting-up, settings and main controls of pumps.

· These operating and maintenance instructions contain MAS DAF MAKINA SANAYI A.Ş. `s suggestions. The special operating and maintenance information of the plumbing that a pump is fitted to is not considered in these instructions. This information must be given by the plumbing constructors only.

Please refer to instructions of plumbing constructors.

· Please pay attention to the warnings in this manual and ensure that it is read before the installation-start up process. MAS DAF MAKINA SANAYI A.S. is not

responsible for the accidents resulting from negligence.

 If you cannot find an answer to your questions in this manual, it is suggested that you contact MAS DAF MAKINA SANAYI A.Ş. Please inform us about the rated value and especially the serial number of the pump when you get in contact for help.

· The safety instructions in this manual cover the current national accident protection regulations. Beside all of these, an operation, work and safety measure imposed by the costumer has to be applied.

## The Signs Used in This Operation Manual



Read the instructions carefully in this operating manual and keep it for your future reference

Warning sign against the electrical risks

Warning sign against the electrical risks

## 1. IMPORTANT SAFETY PRECAUTIONS

In order to minimize the accidents during the mounting and putting into service of the pump, the following rules have to be applied:

1. Do not work without taking safety measures relevant to equipment. Cable, mask and safety band must be used when necessary.

2. Be sure there is adequate amount of oxygen and there is no toxic gaseous around

3. Before using welding or any electrical equipment make sure that there is no risk of explosion.

4. Check the cleanliness of the area to take care of your help. (Dust, smoke, etc.)

5. Do keep in mind that there is a risk of having accidents related to electricity

6. Do not lift the pump before you check the transport equipment.

7. Be sure you have a by-pass line

8. Use helmet, eye glasses and protective shoes for your safety

9. Place a protective barrier around the pump within the necessary safety area

10. Dust, liquids and gaseous that may cause overheating, short circuit, corrosion and fire must be kept away from the pump unit.

11. By checking the noise level of the pump unit. necessary measures to avoid noisy operation of the pump that can have harmful effects on the personnel and environment.

12. Be careful about the direction of transport and storage.

13. Cover appropriately the moving parts to avoid possible injury of the personnel. Mount the coupling guard and belting before starting-up the pump

14. All the electrical and electronic applications must be performed by authorized person conforming EN60204-1 and /or domestic instructions.

- **15.** Protect the electrical equipment and motor against overloading
- **16.** If flammable and explosive liquids are pumped, ground connection of electricity should be carried out properly
- 17. Do not expose the pump unit to sudden temperature variations
- **18.** All personnel who work with the waste water system need to be vaccinated in case of contagious diseases.
- 19. If the pump contains hazardous liquids, one must use protective helmet against the risk of splatter. One also must accumulate the liquid in a proper container against any risk of leakage.

## All Other Health and Safety Rules, Laws and Regulations Must Be Applied

## 2. GENERAL

## 2.1. Definition of Pump and Usage Areas

Jet series are self-priming light horizontal shaft centrifugal pumps. They are used in:

- Households
- · Garden irrigation
- Washing and cleaning applications
- · Small-scale agriculture and horticulture
- Light commercial applications

Pumped liquids: Low viscosity, neutral, non-explosive liquids, not containing solid particles or fibres. The liquid must not attack the pump materials chemically.

## CAUTION

Please contact MAS DAF MAKINA SANAYI A.Ş. for liquids that have different chemical and physical specifications.

## 2.2. Performance Information

Actual performance of the pump can be obtained from the order page and/or from the test report. This information is given on the pump label.

The performance curves given in the catalog are valid for water whose density and viscosity are  $\rho=1$  kg/dm and V=1 cst. respectively. For those liquids whose densities and viscosities are different from those of water, please consult with MAS DAF MAKINA SANAYI A.Ş. since the performance curves vary with density and viscosity

## CAUTION

Do not operate the pump with a motor that has a different power except for the given catalog and label values.

The pump is not to be operated at off-design point given in the order and supplied from the firm.

It is necessary to ensure that the instructions are obeyed for the safe running of the pump.

## 2.3. Warranty Conditions

The entire products in our selling program are warranted by MAS DAF MAKINA SANAYI A.Ş.

The warranty conditions will only be valid when all the instructions about installation and start-up operations of the pump unit are taken into account.

#### 2.4. Test

All Pumps are dispatched for sale when all the performance and pressure tests are completed. Proper assurance of material and fault-free operation of pumps whose performance tests are made is under the warranty of MAS DAF MAKINA SANAYI A.S.

### 3. SAFE OPERATING CONDITIONS

This manual contains main safety instructions for the installation, operation and maintenance. It must be read by the personnel who are responsible for installation and operation. This manual should always be kept near the installation location. It is important to comply with safety precautions stated in page 1 along with the general safety instructions as well as preventive measures repeated in other sections of this manual.

## 3.1. Training of Personnel

Installation, operation and maintenance personnel must have necessary knowledge in order to accomplish the given job. The responsibility, adequacies and controlling duties of such personnel must be determined by the costumer. It has to be certain that these personnel comprehend totally the content of the operating manual.

If the personnel do not have enough knowledge, required training must be given by the costumer. If training support is needed by the costumer, it will be provided by the manufacturer/seller.

### CAUTION

Untrained personnel and unwillingness to comply with safety instructions may be risky for both machine and environment. MAS DAF MAKINA SANAYI A.Ş. is not responsible for this kind of damages.



# 3.2. Hazardous Conditions That May Occur When One does not Comply With the Safety Instructions

Incompliance with safety regulations may put the personnel, the environment and the machine in danger and thus may cause damages. Incompliance with safety regulations may give rise to situations listed below.

# Important operational functions of the factory may stop.

Maintenance may get difficult.

One may get injured by electrical, mechanical or chemical hazards.

## 3.3. Safety Measures for Operator

Dangerous, hot or cold components in the pump area must be covered so that one cannot touch them.

Moving components of the pump (such as coupling) must be covered so that one cannot touch them. Those covers must not be dismounted while the pump is running. Dangers that results from electrical connections must be removed. To get more information about this subject, you can refer to domestic electrical instructions.

## 3.4. Safety Measures for Maintenance and Installation

The costumer must assure that all maintenance, check and installment tasks are performed by qualified personnel. Repair work must only be performed while the machine is not running.

The pump and its auxiliary system must be cleaned thoroughly if it contains hazardous liquids. At the end of the repair work, all safety and protective equipment must be re-installed.

## 3.5. Spare Parts Replacement

Replacement of spare parts and all modifications must be done after contacting with the manufacturer. Spare parts and accessories certified by the manufacturer are important for the safe operation of the system.

**Notice:** MAS DAF MAKINA SANAYI A.Ş. is not responsible from the usage of improper spare parts.

## 4. TECHNICAL INFORMATION

## 4.1. Design


Jet series are self-priming horizontal shaft centrifugal pumps. They are efficent, low noise, little corrosive tolerance, compact structure, good looking, small volume, light weight, etc.

- Jet piump is horizontal shaft self-primming centrifugal pump up to 8 m.
- The key parts of pump; impeller, pump casing, pump

shaft are made of stainless steel.

- Mechanical seal is single face seal. Seal part is made of Carbon / Ceramic / Stainless Steel.
- The connection type is pipe thread connection. See the following pump structure figure.
- Pump material specifications:

Pump Materials	
Pump Casing	Stainless Steel
Impeller	Stainless Steel
Shaft	Stainless Steel
Diffuser	Noryl
Mechanical Seal	Carbon / Ceramic / Stainless Steel





## 5. TRANSPORT AND STORAGE

Suction, discharge and all auxiliary fittings must be closed during transport and storage. Dead-end covers must be removed while the pump unit is being installed.

## 5.1. Transport

Pump and pump group must be carried safely to the installation location by lifting equipment.

## CAUTION

Current general lifting safety instructions must be applied. Please use a suspension system shown in figure while you are carrying and lifting the pump unit. The suspension rings may be broken because of the excessive load and may result in a damage of the pump. Prefer fabric cable for suspension.



Incorrect lifting may damage the pump unit and cause injuries.

## Damages caused in transport

Check the pump when it is delivered to you. Please let us know of there is any damage.

## 5.2. Storage



# Please keep the unit clean and dry area during storage.

If the pump is out of use for a long time, please consider the instructions below.

- 1. If there is water inside the pump, drain it.
- 2. Clean the pump casing and impeller by jetting clean water for a short time.
- 3. Empty water inside the pump casing, suction line and discharge line.
- 4. Add small amount of antifreeze inside the pump casing if it is not possible to empty it completely. Rotate the pump shaft by hand to mix the antifreeze.
- 5. Close the suction and discharge exits with gasket
- 6. Spray an anti-corrosive into the pump casing.
- 7. Rotate the pump shaft by hand once in every month, in order to protect it from freezing and to lubricate the bearings.

### 6. INSTALLATION

### 6.1. Installation

- Pump should be sited in a well ventilated but frost-free position. The distance between pump with motor and other objects should be at least 150 mm, in order to cool the motor by fan with enough air.
- To reduce the head loss of inlet as least as possible, the inlet pipe shall be as short as possible.
- Ensure the check valve is installed in pipe line system before the pump installation to prevent liquid from returning.
- Pump should be fixed in ground or fixed on the brackets on wall. Pump should be safely fixed and stable.
   Pay attention not to let the weight of pipe system on pump to prevent pump from damage.
- Before pump installation, the inlet pipe line shall be cleaned. If there are impurities in the pipe, it is necessary to install a strainer at 0.5 – 1 mm in front of the pump inlet.
- The air pockets shall be avoided when installing the inlet pipe line. (see Fig. 1)




Figure 1: Section Conditions

 $\boldsymbol{\cdot}$  It is necessary to fit a pressure meter to observe and

control operation of pump.

• When the height of pump position is higher than liquid level, in the suction range of pump, a foot valve should be installed in the inlet pipe end. And fit a water pouring screw hole in the drainage pipe. It is used for pouring water in before starting pump.

## 6.2. Electrical Connection

- ${\boldsymbol{\cdot}}$  The electrical connections should be carried out by a qualified electrician.
- •To make sure the motor is suitable for the power supply, cables of the motor must be connected to power supply according to the figure on the terminal box and the motor nameplate.
- Motor shall be connected with a fast and effective motor starter, to ensure that the motor will not be damaged by lack of phase, unstable voltage or overload. The motor shall earthed reliably.

## CAUTION

Before take apart the terminal box cover or dismantle pump, make sure that the power supply is switched off.



## Warning - Electrical connection and safety devices

- The pump units should be connected to the power supply by the appropriately rated power cables according to the motor ratings.
- The pump units should always be equipped with safety devices as required in the standards (EN 809 and/or EN60204-1) as well as by the national rules of the country where the pump is used.
- Despite the rules of any country, the power supply to the pump unit must be equipped with at least following electrical safety devices with appropriate ratings:
- Emergency switch
- Circuit breaker (as a supply disconnecting (isolating)
- device as well as an over current protective device)
- Motor overload protection

## 7. COMMISSIONING, START UP AND OPERATING

## CAUTION

It is prohibited to run without liquid, which will damage mechanical seal and sliding bearing.

## CAUTION

## Do not start your pump dry (WITHOUT WATER).

Fill water in pump in inverse pouring system.

Close the pump outlet valve, release air vent screw on the pump head and open the inlet valve slowly until stable water flows from the air vent screw. Then fasten the screw.



• Fill water in pump when liquid level is lower than pump. Before installing, pump and pipes must be filled with liquid fully and air vented.

## 7.1. Check the rotary direction

Switch on the power supply and view the rotary direction by viewing the motor fan. From the motor end, pump shall run counter-clockwise.

## 7.2. Check before pump start-up

- Check whether the pump is fixed securely.
- Check whether pump is filled with water fully and check whether liquid can flow freely.
- · Check whether the voltage of power supply is stable.
- Check whether it turns correctly.
- To make sure all pipe lines are connected tightly and can supply water normally.
- The valves in the inlet pipe line are completely opened.
- The outlet valve shall be opened slowly after the pump is started up.
- Check the operation pressure if pressure meter is installed.
- Check all the controls for normal operation. If the pump is controlled by pressure switch, check and adjust the starting pressure and stopping pressure. Check the full load current to make sure it not surpasses the max allowed current.

## 7.3. Frequency of pump starts

- Pump should not be started too frequently. It is suggested pump shall not be started more than 100 times per hour if the motor power is less or equal to 4 kW. When motor power is big than 4 kW, pump shall not be started more than 20 times in one hour.
- Suggestion: When pump running, flow should be controlled at the range of 0.5-1.3 times of rated flow.
- There should be no noise when pump running. If there is something wrong, stop pump and check it and repair.

## 7.4. Frost protecting

Pump can be used in the system with anti-frozen measures. If the pump is installed in easily frozen environment, suitable antifreeze shall be added to the transferring liquid to prevent pump from being damaged. If antifreeze is not used, pump shall not be used during periods of frost. Pump should be drained when stops using.

# 7.5. The following should be checked regularly for pump

- · Pump working and operating pressure
- Possible leakage
- · Possible motor overheat
- · Cleaning/replacement of all strainers (If strainers fit)
- · The switch off time of motor overload

- Frequency of starts and stops
- · All control operation

If find faults, check system according to "Possible Failures, Causes, and Solutions"

- Pump shall be cleaned and kept appropriately when it is not used for a long time.
- Pump shall be prevented from being corrupted and damaged in storage.

## 8. MAINTENANCE

## CAUTION

Maintenance operations must be done by authorized personnel with protective clothing only. The personnel must also beware of high temperatures and harmful and/or caustic liquids. Make sure that the personnel read carefully the manual.

- The instructions in Safety Precautions must be executed during maintenance and repair
- Continuous monitoring and maintenance will increase the engine's and pump's lives.

The instructions below should be applied.

## 8.1. The Checks During the Operation

- · Pump must never be operated without water.
- Pump must not be operated for a long time with the discharge valve closed (zero capacity).
- Bearing temperature must never exceed 60°C if the ambient temperature is 30°C
- Precautions must be taken against flare up when the component temperatures are over 60°C. "Hot Surface" warnings must be placed over necessary areas.
- All the auxiliary systems must be in use while the pump is operating.
- •There is no need for excessive maintenance because of using mechanical seal. Water leakage from the mechanical sealing indicates the fact that the sealing is worn out and therefore needs to be replaced.
- If the system consists of a substitute pump, keep it ready by operating it once a week. Check also the auxiliary systems of the substitute pump.

## 8.2. Service

Our Customer Service Department offers after-sale service. Manager should employ authorized and trained personnel for mounting / dismounting procedures. Before these procedures, one must make sure that pump interior is clean and empty.

This criterion is also valid for the pumps which are sent to our factory or to our service points.



Maintain the safety of the personnel and the environment in every field procedure.

## 8.3. Spare Parts

The spare parts of Jet type pumps are guaranteed for 10 years by MAS DAF MAKINA SANAYI A.Ş.

In your spare parts requests, please indicate the below listed values that are indicated on your pump's label.

Pump type and size: Motor power and speed: Pump serial number: Capacity and head:

## 9. POSSIBLE FAILURES, CAUSES, SOLUTIONS


Possible failures and solution strategies are listed in the table below. Please apply to the Customers' Service Department of our company when a generic solution is not found to your problem.



## While the failures are repaired the pump must always be dry and un-pressurized.


POSSIBLE FAILURE	CAUSES	SOLUTIONS	REMARKS
Motor does not run when started.	a) Power supply failure. b) Fuses are blown. c) Motor is overloaded. d) Main contacts of starter are not connected well or the coil is defective. e) Control circuit is defective. f) Motor is defective.	a) Check power supply. b) Replace fuses. c) Check system. d) Replace motor starter. e) Check control circuit. f) Repair.	
Overload device of motor starter trips out immediately when power supply is switched on.	a) Fuses are blown.     b) Contacts of overload device are faulty.     c) Cable connection is loose or faulty.     d) Motor winding is defective.     e) Pump mechanically blocked.	a) Replace fuses. b) Check motor starter. c) Check cables and power supply. d) Replace motor. e) Check and repair pump.	In the case of d) and e), users shall not disassemble the pump by themselves.
Overload device trips out occasionally.	a) The setting of overload is too low.     b) Periodic power supply faults.     c) Low voltage at peak times.	a) Reset overload setting.     b) Check power supply.     c) Add regulator.	
Motor starter has not tripped out but the pump does not run.	a) Contacts of starter are not contacted well or the coil is faulty.     b) Control circuit are defective	a) Change motor starter.     b) Check control circuit.	
Pumped water does not flow constantly.	a) Suction pipe is too small. b) There is not sufficient water in pump water inlet. c) Liquid level is low. d) Pump inlet pressure is too low compared with water temperature, pipeline loss and flow. e) Suction pipe is blocked by impurities.	a) Enlarge inlet pipeline. b) Improve system and increase coming water. c) Try to lift liquid level. d) Improve system and try to increase the inlet pressure. e) Check and clear impurities.	
Pump runs but gives no water.	a) Suction pipe is blocked by impurities.     b) Foot valve or check valve is closed.     c) Leakage in suction pipe.     d) There is air in suction pipe or pump.	a) Check and clean suction pipe. b) Check and repair foot valve or check valve. c) Check and repair suction pipe. d) Refill liquid, release air.	
Pump runs backwards when switched off.	a) Leakage in suction pipe.     b) Foot valve or check valve is defective.     c) Foot valve is blocked in opened or partly opened position.     d) There is air in suction pipe.	a) Check suction pipe.     b) Check and repair foot valve or check valve.     c) Check and repair foot valve.     d) Check and repair suction pipe and release air.	
Abnormal vibration or noise from pump.	a) Leakage in suction pipe.     b) Suction pipe is too small or suction pipe is partly blocked by impurities.     c) There is air in suction pipe or pump.     d) The comparison of the delivery head of device with delivery head of pump is very low.     e) Pump mechanically blocked.	a) Check and repair suction pipe. b) Enlarge or check situation pipe. c) Refill liquid to the pump and vent air. d) Improve system or choose another pump model. e) Check and repair pump.	In the case of e), users shall not disassemble the pump by themselves.

## 10. SECTIONAL DRAWING AND PART LIST FOR Jet PUMP



Part No	Parça Adı	Part No	Parça Adı	Part No	Parça Adı
2	Pump Casing	200	Deep Groove Ball Bearing	360	Nut
4	Plastic Diffusor	210	Key (Impeller)	370	Nut (Impeller)
20	Impeller	220	Oil Seal	400	0-Ring
50	Mechanical Seal Bushing	250	Mechanical Seal	401	0-Ring
52	Mechanical Seal Thrust Bushing	260	Plug 1/4 "	402	0-Ring
55	Motor Cover	261	Plug 1/2 "	600	Electric Motor
60	Motor Shaft	320	İmbus Bolt		

## 11. DRAWING FOR DISMANTLING AND PART LIST FOR Jet PUMP



Part No	Parça Adı	Part No	Parça Adı	Part No	Parça Adı
2	Pump Casing	200	Deep Groove Ball Bearing	360	Nut
4	Plastic Diffusor	210	Key (Impeller)	370	Nut (Impeller)
20	Impeller	220	Oil Seal	400	0-Ring
50	Mechanical Seal Bushing	250	Mechanical Seal	401	0-Ring
52	Mechanical Seal Thrust Bushing	260	Plug 1/4 "	402	0-Ring
55	Motor Cover	261	Plug 1/2 "	600	Electric Motor
60	Motor Shaft	320	İmbus Bolt		















Orta Neighborhood Atayolu Street No:16 Tuzla - Istanbul / Turkey +90 216 456 47 00

